

MATERIAL	Hardness: ≤ 28 Rc (≤ 271 HBn)														
	SFM	Chip Load by Neck Diameter (IPT)													
		0.015	0.031	0.047	0.062	0.078	0.093	0.125	0.187	0.250	0.312	0.375	0.500	0.625	0.750
ALUMINUM ALLOYS															
Casting (2xx, 5xx, 7xx, 8xx)	750	.00017	.00034	.00052	.00068	.00086	.00102	.00138	.00206	.00275	.00343	.00413	.00550	.00688	.00825
Wrought (1xxx, 2xxx, 3xxx, 5xxx, 6xxx, 7xxx, 8xxx)	1000														
Casting - 3%-5% Si (3xx, A3xx, C3xx, 4xx, A4xx, B4xx)	750														
Casting - 5%-8% Si (3xx, A3xx, C3xx, 4xx, A4xx, B4xx)	700														
Casting - 8%-12% Si (3xx, A3xx, C3xx, 4xx, A4xx, B4xx)	650	.00015	.00031	.00047	.00061	.00077	.00092	.00124	.00185	.00248	.00309	.00371	.00495	.00619	.00743
Casting - 12%-16% Si (3xx, A3xx, C3xx, 4xx, A4xx, B4xx)	475														
Wrought - 5%-8% Si (4xxx)	1000														
Wrought - 8%-12% Si (4xxx)	800														
MAGNESIUM ALLOYS	1500	.00017	.00034	.00052	.00068	.00086	.00102	.00138	.00206	.00275	.00343	.00413	.00550	.00688	.00825
ZINC ALLOYS	800														
COPPER ALLOYS															
High Coppers - 90%+ (C1xxxx)	225														
Brass (Copper Zinc alloys, C2xxxx, C3xxxx, C4xxxx, C6400-C69800)	500														
Phosphor Bronzes (Copper Tin alloys, C5xxxx)	225														
Aluminum Bronzes (Copper Aluminum alloys, C60600-C64200)	500	.00013	.00027	.00041	.00055	.00069	.00082	.00110	.00165	.00220	.00275	.00330	.00440	.00550	.00660
Silicon Bronzes (Copper Silicon alloys, C64700-C66100)	500														
Copper Nickels, Nickel Silvers (Copper Nickel alloys, C7xxxx)	225														
Cast Copper Alloys (C83300-C86200, C86400-C87900, C9200-C95800, C97300-C97800, C99400-C99700)	550														



Speeds & Feeds

Product Table: Dovetail Cutters - Parker Hannifin O-Ring Dovetail Roughers
WITHOUT Drop Hole Allowance
Series: 7152xx

Product Notes:

Posted Radial Passes reflect machining on one side of groove at full axial depth
 If machining on both sides of part, reduce Chip Loads (IPT) by 40%

O-Ring grooves require machining with circular interpolation. The Linear Feed must be reduced to account for angular velocity (see example).

General Notes:

All posted speed and feed parameters are suggested starting values that may be increased given optimal setup conditions. Chip loads reflect uncoated cutters and may be increased 5%-10% if coated. For ferrous materials with hardness ≤ 28 Rc, chip loads can be increased 5%-10%.

If you require additional information, Harvey Tool has a team of technical experts available to assist you through even the most challenging applications. Please contact us at **800-645-5609** or Harveytech@harveyperformance.com.

WARNING: Cutting tools may shatter under improper use. Government regulations require use of safety glasses and other appropriate safety equipment in the vicinity of use.

MATERIAL	Hardness: 29-37 Rc (279-344 HBn)														
	SFM	Chip Load by Neck Diameter (IPT)													
		0.015	0.031	0.047	0.062	0.078	0.093	0.125	0.187	0.250	0.312	0.375	0.500	0.625	0.750
CARBON STEELS															
Free-Machining/Low Carbon steels, 10xx - 1029 & all 10Lxx, 11xx - 1139 & all 11Lxx, 12xx - 1215 & all 12Lxx	600	.00006	.00012	.00018	.00023	.00029	.00035	.00047	.00071	.00095	.00118	.00142	.00189	.00236	.00284
1030 - 1095, 1140 - 1151, 13xx, 15xx, 2xxx, 3xxx, 4xxx & 4xLxx, 5xxx & 5xLxx, 51xxx & 50Lxxx, 51xxx & 51Lxxx, 52xxx & 52Lxxx, 6xxx, 8xxx, 9xxx	200	.00005	.00011	.00016	.00021	.00027	.00032	.00043	.00065	.00086	.00108	.00130	.00173	.00216	.00259
STAINLESS STEELS															
203 EZ, 303 (all types), 416, 416Se, 416 Plus X, 420F, 420FSe, 430F, 430FSe, 440F, 440FSe	450	.00006	.00012	.00018	.00023	.00029	.00035	.00047	.00071	.00095	.00118	.00142	.00189	.00236	.00284
201, 202, 203, 205, 301, 302, 304, 304L, 308, 309, 310, 314, 316, 316L, 317, 321, 329, 330, 347, 348, 385, 403, 405, 409, 410, 413, 420, 429, 430, 434, 436, 442, 446, 501, 502	200	.00005	.00011	.00016	.00021	.00027	.00032	.00043	.00065	.00086	.00108	.00130	.00173	.00216	.00259
414, 431, 440A, 440B, 440C, 13-8, 15-5, 15-7, 17-4, 17-7	150	.00003	.00007	.00010	.00013	.00017	.00020	.00027	.00040	.00054	.00067	.00081	.00108	.00135	.00162
TOOL STEELS															
A, L, O, P, W series	200	.00005	.00011	.00016	.00021	.00027	.00032	.00043	.00065	.00086	.00108	.00130	.00173	.00216	.00259
D, H, M, T, S series	150	.00003	.00007	.00010	.00013	.00017	.00020	.00027	.00040	.00054	.00067	.00081	.00108	.00135	.00162
TITANIUM ALLOYS	150	.00003	.00007	.00010	.00013	.00017	.00020	.00027	.00040	.00054	.00067	.00081	.00108	.00135	.00162
HIGH TEMP ALLOYS															
Inconel, Hastelloy, Waspalloy, Monel, Nimonic, Haynes, Discoloy, Incoloy	70	.00003	.00007	.00010	.00013	.00017	.00020	.00027	.00040	.00054	.00067	.00081	.00108	.00135	.00162

MATERIAL	Hardness: 38-45 Rc (353-421 HBn)														
	SFM	Chip Load by Neck Diameter (IPT)													
		0.015	0.031	0.047	0.062	0.078	0.093	0.125	0.187	0.250	0.312	0.375	0.500	0.625	0.750
CARBON STEELS															
Free-Machining/Low Carbon steels, 10xx - 1029 & all 10Lxx, 11xx - 1139 & all 11Lxx, 12xx - 1215 & all 12Lxx	600	-	-	-	-	-	-	-	-	-	-	-	-	-	-
1030 - 1095, 1140 - 1151, 13xx, 15xx, 2xxx, 3xxx, 4xxx & 4xLxx, 5xxx & 5xLxx, 51xxx & 50Lxxx, 51xxx & 51Lxxx, 52xxx & 52Lxxx, 6xxx, 8xxx, 9xxx	200	-	-	-	-	-	-	-	-	-	-	-	-	-	-
STAINLESS STEELS															
203 EZ, 303 (all types), 416, 416Se, 416 Plus X, 420F, 420FSe, 430F, 430FSe, 440F, 440FSe	450	-	-	-	-	-	-	-	-	-	-	-	-	-	-
201, 202, 203, 205, 301, 302, 304, 304L, 308, 309, 310, 314, 316, 316L, 317, 321, 329, 330, 347, 348, 385, 403, 405, 409, 410, 413, 420, 429, 430, 434, 436, 442, 446, 501, 502	200	.00003	.00005	.00008	.00011	.00013	.00016	.00022	.00032	.00043	.00054	.00065	.00086	.00108	.00130
414, 431, 440A, 440B, 440C, 13-8, 15-5, 15-7, 17-4, 17-7	150	.00002	.00003	.00005	.00007	.00008	.00010	.00014	.00020	.00027	.00034	.00041	.00054	.00068	.00081
TOOL STEELS															
A, L, O, P, W series	200	.00003	.00005	.00008	.00011	.00013	.00016	.00022	.00032	.00043	.00054	.00065	.00086	.00108	.00130
D, H, M, T, S series	150	.00002	.00003	.00005	.00007	.00008	.00010	.00014	.00020	.00027	.00034	.00041	.00054	.00068	.00081
TITANIUM ALLOYS	150	.00002	.00003	.00005	.00007	.00008	.00010	.00014	.00020	.00027	.00034	.00041	.00054	.00068	.00081
HIGH TEMP ALLOYS															
Inconel, Hastelloy, Waspalloy, Monel, Nimonic, Haynes, Discoloy, Incoloy	70	.00002	.00003	.00005	.00007	.00008	.00010	.00014	.00020	.00027	.00034	.00041	.00054	.00068	.00081

O-Ring Rougher Guide

Dovetail and O-ring style cutters have a variety of applications ranging from customized grooves to tricky seals. Unfortunately, they are very fragile due to their trapezoidal profile of a large Cutter Diameter with a smaller Neck Diameter. This combination of features demands specific machining parameters to avoid breakage.

Speeds & Feeds calculations:

1. Determine the correct SFM and Chip Load (IPT) for the rougher and material
2. Calculate the Speed (RPM) and Linear Feed (IPM)
3. Adjust Linear Feed to account for Angular Velocity due to Circular Interpolation
4. Determine Radial Passes at full axial depth
5. Repeat steps 1-4 with the paired cutter
6. Conclusion
7. Additional Tips

Example: Tool #715221 is roughing out a o-ring groove that will fit a AS568-204 seal in 4140 steel at 32 Rc

1. The Cutter Diameter for the tool is .113" and is used to find SFM and calculate Speed (RPM).
The Neck Diameter is .079" and is used to find Chip Load (IPT) and calculate Linear Feed (IPM).
Using the Speeds & Feeds chart (next page), SFM is 200 and the Chip Load (IPT) is .00016.

2. Calculate Speed (RPM) and Linear Feed (IPM)

$$\begin{aligned} \text{RPM} &= (\text{SFM} \times 3.82) / \text{Cutter Diameter} & \text{Linear Feed (IPM)} &= \text{RPM} \times \text{IPT} \times \text{Number of Flutes} \\ &= (200 \times 3.82) / .113 & &= 6761 \times .00027 \times 2 \\ &= 6761 & &= 3.65 \end{aligned}$$

3. Adjust Linear Feed (see O-Ring Feed Rate Adjustment chart)

$$\begin{aligned} \text{Adjusted Feed} &= [(\text{Groove Major Dia} - \text{Cutter Dia}) / \text{Groove Major Dia}] \times \text{Linear Feed} \\ &= [(.519 - .113) / .519] \times 3.65 \\ &= 2.86 \end{aligned}$$

4. Using Table 1, locate the Item # and determine the Max Radial DOC and the Number of Radial Passes needed at full Axial depth. Then using Table 3, determine the actual descending radial stepover for each pass:

4 Radial Passes at 46%, 25%, 18%, and 11% of .017 Max Radial Depth of Cut.

5. Using Table 2, find the paired O-Ring Cutter. Repeat steps 1-4 using the paired cutter. Make sure to adjust the feed rate and radial passes when doing so.

Tool #23921, 6761 RPM, 2.16 IPM adjusted to 1.69, 9 radial passes at 64%, 8%, 7%, 6%, 5%, 4%, 3%, 2%, 1% of .0335 Max Radial Depth of Cut.

6. Conclusion

In this example, the rougher, Tool #715221, would run at 6761 RPM, 3.65 IPM and make 4 radial passes of .0078, .0042, .0031, .0019 on each side of the groove at full axial depth.

Then the cutter, Tool #23921, would run at 6761 RPM, 1.69 IPM, and make 9 radial passes of .0214, .0027, .0023, .0020, .0017, .0013, .0010, .0007, .0003 on each side of the groove at full axial depth.

7. Additional Tips

Please note that tools are very fragile (some more than others) due to reduced neck design and flute runout through neck. Given that torque is generated on the larger head diameter and is multiplied as it is transferred to neck of tool, care must be taken when using these tools. Each successive stepover will increase tool engagement, requiring a descending radial stepover to avoid

Setup and Application (Series 7152xx and 239xx for use alongside Series 239xx without drophole)

- Rough out slot with appropriate O-Ring Slotting End Mill (see series 565xx) or with other comparable end mill.
- Insert O-Ring Rougher into slot at full axial depth.
- Mill multiple passes with descending radial stepover as calculated using Tables 1 & 3 on both sides of part.
- Insert paired O-Ring Cutter (see table 3) into roughed out slot at full axial depth.
- Mill multiple passes with descending radial stepover as calculated using Tables 1 & 3 on both sides of part.
- These tools are able to mill both Full and Half O-Ring grooves. As such, a corner radius at the top of the part must be machined for final groove form (see series 170xx).




TABLE 1

Item ID	Max Radial DOC	Radial Passes per Side		
		≤ 28 Rc	29 - 37 Rc	38 - 45 Rc
715207	0.0080	2	3	4
715214	0.0150	3	4	5
715221	0.0170	3	4	5
715228	0.0300	3	4	5
715235	0.0360	3	4	5
715242	0.0470	3	4	5
23907*	0.0159	6	9	11
23914*	0.0287	9	11	13
23921*	0.0335	6	9	11
23928*	0.0591	9	11	13
23935*	0.0700	6	9	11
23942*	0.0896	6	9	11

*The amount of passes for the listed tools have been adjusted to account for the use of the paired dovetail rougher. **DO NOT** use these numbers without first using the paired rougher.

TABLE 2

Paired O-Ring Roughers and O-Ring Cutters						
Rougher Item ID	715207	715214	715221	715228	715235	715242
Cutter Item ID	23907	23914	23921	23928	23935	23942

TABLE 3

Radial Passes	Percentage of Cutter's Maximum Radial Depth of Cut														
2	70%	30%													
3	50%	30%	20%												
4	46%	25%	18%	11%											
5	46%	25%	16%	8.0%	5.0%										
6*	69%	12%	9.0%	6.0%	3.0%	1.0%									
7*	73%	9.0%	7.0%	5.0%	3.0%	2.0%	1.0%								
9*	64%	8.0%	7.0%	6.0%	5.0%	4.0%	3.0%	2.0%	1.0%						
10*	67%	7.5%	6.5%	5.5%	4.5%	3.5%	2.5%	1.5%	1.0%	0.5%					
11*	62%	8.0%	7.0%	6.0%	5.0%	4.0%	3.0%	2.0%	1.5%	1.0%	0.5%				
12*	63%	7.0%	6.0%	6.0%	5.0%	4.0%	3.0%	2.0%	2.0%	1.0%	0.5%	0.5%			
13*	60%	6.0%	6.0%	5.0%	5.0%	4.0%	4.0%	3.0%	2.0%	2.0%	1.0%	1.0%	0.5%	0.5%	